
SCAG POWER EQUIPMENT



KEY IDENTIFYING FEATURES ALL UNITS LISTED

PUMP AND MOTOR DRIVE SYSTEM
HYDROSTATIC OIL RESERVOIR
EYEBOLT TURNBUCKLE ENGAGEMENT SYSTEM
SPEED ADJUSTMENT LEVER

MODEL#


SWZ36-14KA SWZ36-14KH SWZ48-14KA SWZ48-14KH

SWZ-14KA SWZ-14KH SWZ-18KH SWZ-20KHE

> SWM-52 SWM-61 SWM-72

> > **SWF**

36" CUTTER DECK




36" CUTTER DECK

Ref	. Part		Ref	. Part	
No.	Number	Description	No.	Number	Description
1	46087	Cutter Deck (Includes Decais)	39	46085	Belt Cover Assembly (Includes Decal)
2	46020	Cutter Spindle Assy. (Includes Items 3-9)	40	•	Washer, 25/64 x 15/16 x 12 ga
3	04050-04	Retaining Ring, 1° ExtInverted	40a	•	Washer, 13/32 x 13/16 x 16 ga.
4	04050-07	Retaining Ring, 2-7/16 InLbsc	41	04022-04	Wing Nut, 3/8-16 Elastic Stop
5	48101-02	Bearing, Spindle	42	48127	Pulley (Includes Items 43-44)
6	41001	Spindle Housing	43	48141	Tapered Hub
7	48114-02	Grease Fitting, Str., S/15 Serr	44	•	Hex Hd. Bolt. 1/4-20 x 3/4
8	43001-02	Spindle, Cutter Blade	45	•	Hex Nut, 5/8-11
9	D4041-02	Washer, 1-5/16 x 2-7/16 x 16 ga.	46	48204	Belt, Blade Drive
10	D4063-08	Key, 14 x 14 x 2	47	•	Hex Hd. Bott 3/8-16 x 5
11	43038	Spacer, Cutter Blade	48	•	Hex Nut, 3/8-16
12	•	Hex Hd. Bolt, 5/16-18 x 1-1/4	48a	•	Hex Nut, 3/8-16 Ctr Locknut
13	•	Lockwasher, Spring, 5/16	49	•	Lockwasher, Spring 3/8
14	•	Hex Nut, 5/16-18	50	04004-02	Support, Belt Cover
14a	•	Hex Nut, 5/16-24	51	45098	Belt Guide
15	48108	Cutter Eface 18"	52	•	Hex Hd. Bolt, 7/16-14 x 1-1/4
152	48185	Curter Blade 18" Hi Litt	53	•	Washer, 15/32 x 59/64 x 16 ga.
16	G404G-10	Flat Washer, 5/8 W	54	•	Lockwasher, Spring, 7/16
17	04001-41	Hex Hd. Bolt, 5/8-11 x 9-1/2	55	•	Hex Nut, 7/16-14 Elestic Stop
18	46079	Caster Assembly (Includes Items 19-28)	56	45107	ider Pivot
19	04066-01	Quick Pin	57	46145	Idler Arm Assy. (Includes Items 22 & 58)
20	43037-01	Spacer, Caster Yoke, 1/2" long	58	48100-05	Bronze Bearing
21	48100-01	Bronze Bearing	59	04050-02	Retaining Ring, 3/4 Ext"E"
22	48114-01	Grease Fitting, Str. 1/4-28	60	04004-04	Stud
23	46082	Support Assembly.	61	48269	Idler Pulley, Belt Clutch
	45006	Caster Yoke	52	43063	Specer, idler
25	43022	Sleeve, Caster Wheel Brg.	63	70-02	Eyebott, LH
25	D4001-37	Hex Hd. Bott, 1/2-13 x 5-1/2	64	04070-01	Eyebott, RH
27	•	Hex Locknut, 1/2-13	65	43025	Turnibucide
28	48307-01	Wheel Assy. (Includes 13-14a, 29-34)	68	04022-02	Wing Nut, 5/16-18
29	48307-02	Tire Only Caster Wheel	67	43042	Sleeve, Clutch Rod
	48006-03	Inner Tube only	68	•	Hex Hd. Bolt, 3/8-16 x 2-3/4
30	48307-04	Rim Pair, Caster Wheel	69	44064	Blade Clutch Rod, Lower
31	48006-07	Retainer, Bearing, Caster Wheel	70	43043	Sleeve, Clutch Rod
32	48006-06	Roller Bearing, Caster Wheel	71	•	Cotter Pin, 3/32 x 1
33	48114-03	Greese Fitting, 45' 1/4-28	72	•	Washer 33/64 x 1 x 16 ga.
34	48006-05	Hub Assembly	73	0.162.01	Hair Pin, Large
35		Hex Hd Bolt, 5/16-18 x 3/4	74	•	Hex Hd. Bolt. 3/8-16 x 1
36	4510G	Discharge Chute	75	42057	Cam Link
37	•	Hex Nut, 5/16-18 Elastic Stop	76	44009	Belt Guide
38	•	Hex Hd Balt, 5/16-18 x 1	77	04041-08	Washer, 3/4 x 1-1/4 x 035

^{*} Common hardware which should be purchased locally. All bolts are Grade 5 plated, all other fasteners are zinc plated.


48", 52", 61", & 72" CUTTER DECKS



48", 52", 61", & 72" CUTTER DECKS

	. Part No.	Description	48 52 61 72	1	Part No.	Description	48	52 6	j1 7 :
1	46088	Cutter Deck (includes decals)	×	42a	48299	Pulley (Includes 43-44)			×
1	46163	Cutter Deck (Includes decals)	x	43	48141	Tapered Hub	X	X 3	x x
ı	46119	Cutter Deck (includes decals)	X	44	•	Hex Hd. Bolt, 1/4-20 x 3/4	X	x)	x x
1	46194	Cutter Deck (Includes decals)	x	45	•	Hex Nut, 5/8-11	x	x ;	x x
2	46020	Cutter Spindle Assy. (Includes 3-9)		1	48412	Pulley, Double (Includes 43-44)	¥	x 3	¥
	D4050-G4	Retaining Ring, 1" ExtInverted	x x x x	1	48302	Pulley, Double (Includes 43-44)		Ē.	
	D4050-07	Retaining Ring, 2-7/16" Int.basic	x		48087	Beit, RH Blade Drive	×		
	48101-02	Bearing, Cutter Spindle	X		48285	Belt, RH Blade Drive		x	
	41001	Spindle Housing	XXXX		48265	Bett. RH Blade Drive		٠,	
	48114-02				48295	Belt RH Blade Drive		200	
 	43001-02	Greese Fitting Str. 5/16 Serr. Spindle, Cutter Blade	XXXX		48089	Belt, Blade Drive		82.263	×
)	04041-02	Washer, 1-5/16 x 2-7/16 x 16 ga.	x x x x		48286		X	_	
	04063-08	The state of the s	x		48264	Belt, Blade Drive		X .	
0		Key, 1/4 x 1/4 x 2				Belt, Blade Drive		,	X
1	43038	Spacer, Cutter Blade	XXXX		48296	Belt, Blade Drive			. Х
2	-	Hex Hd. Bolt, 5/16-18 x 1-1/4	x	49	-	Hex Hd. Bolt, 3/8-16 x 5"		X	
3		Lockwaster, Spring, 5/15	* * * *	50		Hex Nut, 3/8-16		X.	Addition to the
•		Hex Nut. 5/16-18	* * * *	50a		Hex Nut. 3/8-16, Cersterlock		X.	1000000
42		Hex Nut, 5/16-24	* * * *	51		Lockwasher, Spring, 3/8	acceptant 5.49	X	Section 2
5	48110	Cutter Blade 16-1/2*	x		04004-02	Support, Belt Cover		X	95000000
5	48108	Cuter Blade 18"	¥		45098	Belt Guide	********		X)
5	48111	Cutter Blade 21°	×	54	•	Hex Hd. Bolt, 7/16-14 x 1-1/2	X		x)
5	48112	Cutter Blade 24*	X	55	•	Washer, 15/32 x 59/64 x 16 ga.	X	X :	X)
5a	48184	Cutter Blade 16-1/2" Hi Lift	X	56	•	Lock Washer, Spring, 7/16	X	X 2	X)
5a	48185	Cutter Blade 18° Hi Lift	x	57	•	Hex Nut, 7/16-14	X	X :	X)
6	04040-10	Flat Washer, 5/8° W	x	58	48181	Idler Pulley, "V" Groove		X :	
7	04001-41	Hex Hd. Bolt, 5/8-11 x 9-1/2*	x x x x	58	04050-02	Retaining Ring, 8/4" Ext. "E"	***	X	x)
8	46079	Caster Assy, Comp. (incl. 19-28)	x	60	45081	fdler Arm Assy. (Includes 22 & 61)		*	
9	04066-01	Quick Pin	* * * * *	61	48100-05		CONTRACTOR OF THE	× ×	x >
9	43037-01	Spacer, Caster Yoke, 1/2" thick	X	62	43028	J Rod, latter Pull		X	
1	48100-01	Bronze Bearing	X X X X	63	43077	Specer, J Putt Rod		X	
2	48114-01	Grease Fitting, Str., 1/4-28	x	64	04041-12	Washer, 3/8 x 1-1/2 x 16 ga.		X X	
23	46082	Support Assy. (incl. 21-22)	x x x x	65	•	Hex Hd. Bolt, 3/8-16 x 2-1/4		X	
4	45006	Caster Yoke	x x x x		04004-04	Stud		X	
5	43022	Sleeve, Caster Wheel Bearing	XXXX	66	•	Hex Nut, 3/8-16 Elastic Stop		x	
6	04001-37	· · · · · · · · · · · · · · · · · · ·	xxxx		46145	Idler Arm (includes 22 & 61)		X	
78	3400 1-37	Hex Lockout, 1/2-13	x x x x	68	43063	Spacer			·
8	48307-01	Wheel Assy. (incl. 13-14, 29-34)			04070-02			x	
******	48307-02			70	04070-01	Eyebolt RH		0.000	Ŷ.
3	40005-02	Tire only, Caster Wheel Inner Tube only, Caster Wheel	* * * * *	71	43025	Eyendichin Tumbudde		ì	
					04022-02			X X	
	48307-04	Rim Pair, Caster Wheel Retainer Bearing Caster Wheel							
FT	48006-07			73	43042	Sieeve, Cam Clutch			X
2	48006-06	Roller Bearing, Caster Wheel	x x x x	74	4000	Hex Hd Bolt, 3/8-16 x 2-3/4		x	
3	48114-03	Grease Fitting 45' 1/4-28	x x x x	75	45037	Idler Pivot		X	
4	48006-05	Hub Assy. (incl. bolts)	x	76	48269	Idler Pulley, Belt Clutch		X	
5	•	Hex Hd. Bolt, 5/16-18 x 3/4*	x	77	44064	Blade Clutch Rod, Lower	and the second	X	and second
Ş	45029	Discharge Chate	x x x		43043	Sleeve, Clutch Rod	×		X
6	45100	Discharge Chase	×	79		Cotter Pin, 3/32 x 1	×	X	¥
7	•	Hex Nut, 5/16-18 Elastic Stop	* * * *	80	•	Washer, 33/64 x 1 x 16 ga.	X	X	×
18	•	Hex Hd Bolt 5/16-18 x 1	* * * *	81	04062-01	Hair Pin Large	X	X	X
9	46086	Belt Cover (Includes decals)	*	82	•	Hex Hid Bolt, 3/8-16 x 1	×		
9	46164	Belt Cover (Includes decals)	X	83	42057	Cam Link	×	*******	X
39	46121	Belt Cover (includes decals)	×	84	45046	Roller Shaft	X		X
19	46312	Belt Cover (includes decals)	×	85	48038	Guide Roller	x		x
	40312	Washer 25/64 x 15/16 x 12 ga.	x x x x	86		Flat Washer, 11/32 x 11/16 x 16 ga			x
10				87	44008	Belt Guide	. X		x ·
11	04022-04	Wing Nut, 3/8-16	XXXX			Flat Washer, 3/4 x 1-1/4 x .035			
12	48127	Pulley (Includes 43-44)	x	88		FIGI. VI 651 (81, 3/4 X 1-1/4 X .U33	X	X	^

^{*} Common hardware which should be purchased locally. All bolt Grade 5 plated, all other fasteners zinc plated.



ENGINE DECK

HEF. NO.	PART NO.	DESCRIPTION	14KA	14KH	18KH	20KHE
						EUKITE
1	45270	Engine Deck	X	X	x	x
2a	48528	Engine 14H Kawasaki	x			
2a	48357	Engine 14HP Kohler		x		
2 b	48268	Engine 18HP Kohler (MV18 PS-58511)			X	
2b	48358	Engine 20HP Kohler El. St. (MV20 PS-57508)				×
3	*	Bolt, Hex Hd. Metric 8 x 30	x	, x		
3	*	Hex Hd. Bolt, 5/16-18 x 1-1/2			x	×
4	•	Hex Nut, 5/16-18 Elastic Stop			x	×
5	*	Lockwasher, 5/16 Spring	x	x	. x	×
6	48431	Pipe, 4.75" Nipple			x	×
7	48257	Pipe Cap			X	x
8	48059-01	Fuel Hose Clamp	x	x	x	x
9	04050-10	Retaining Ring, 1/2 "E"	x	x	x	x
10	45283	Shaft Widmt RH Pump Control	x		X	x
_				X		
11	46324	Lever Assembly, Pump Control - RH	X	X	X	X
12	48436	Pump, Sunstrand BDP-10L100	· X	. X	X	X
13	*	Bolt, Carriage, 3/8-16 x 1-1/4	X	X	X	X
14		Lockwasher, 3/8	. x	x	×	X
15	•	Hex Nut, 3/8-16	X	X	X	×
16	48484-01	Elbow, 90 deg. Female 1/4 NPT to 1/4 JIC Male	x	x	x	×
17	48117	Plug, 3/8 NPT	x	x	x	x
18	48491	Tee, Galvanized 3/8 NPT	x	x	×	x
19	48353-02	Coupling, 7/16-20 SAE Flare Swivel to 1/4" Hose Push On	x	×	X	×
20	48482-03	Hose, 1/4" ID, 8" Long	x %	x	x	x
21	48350-03	Elbow, 90 deg. 7/16-20 JIC to 7/16-20 "O" Ring	X .	X	X	x
22	48352-03	Coupling, 3/8 Straight Male NPT to 1/2" Hose Push On		i x	x	x
23	48351-05	Hose, 1/2" ID, 12" Long	x x	X	x	X
24	48486-01	Elbow, 90 deg. Male 1/4 NPT to 1/4" Hose Push On	1	n Â		x
-	-	Coupling, 1/4 Straight Male NPT to 1/4" Hose Push On	ar de l'implement X orse	- C	X	
25	48352-02		X	X	×	X
26		Bolt, Hex Hd., 5/16-18 x 2-1/2	X	X	X	X
27	48353-01	Coupling, 3/4-16 SAE Flare Swivel to 1/2" Hose Push On	X	X	X	X
28	48489-02	Elbow, 90 deg. Male 3/4-16 JIC to 1/2" Male NPT	X	X	X	X
29	48471	Oil Filter Assembly (Includes item 70)	X	×	X	x
30	46323	Lever Assembly, Pump Control - LH	X	· 🗶	. • X	x
31	48015	Battery				x
32	•	Carriage Hd. Bolt, 1/4-20 x 6	x	X	x	x
33	•	Flatwasher, 3/8	X	. X	x	, x ,
34	45302	Battery Box				X
35	42745	Battery Clamp	12 m			×
		Wing Nut, 1/4-20 Elastic Stop	J		J	x
36	04022-01		x	x	X	^
37	45125	Sulky Mounting Bracket (Included with Riding Sulky)				
38	•	Bolt, Hex Hd., 3/8-16 x 1-1/4	X	X	X	X
39	*	Hex Nut, 5/16-18	X	X	X	×
40	•	Lockwasher, 5/16	x	X	X	X
41	48534	Cover, Sulky Mount	×	x	X	×
42	•	Bolt, Hex Hd., 3/8-16 x 2-3/4	×	x	x	x
43	•	Bolt, Hex Hd., 3/8-16 x 1	. x	x	x	.х.
44	48468	Wheel Assembly (Incl. 45, 46, 47, 48)	x	X.	x	x
45	48004-02	Tire, 16 x 6.50, 2 ply	×	x	X	x
46	48004-04	Pim Assembly	x	x	x	X
	48468-05	Wheel Hub (Includes item 48)	x	x	x	x
47						x
48	48004-06	Bolt and Nut	X	X	X	
49	04027-02	Hex Castle Nut, 3/4-28 UNEF	X	X	X	. X
50	48437	Motor, White RS	X	x	×	×
51	•	Cotter Pin, 3/32 x 1-1/4	X	Х	×	X
52	04063-15	Key, 3/16 x 3/16 x .75	×	x	· x _	×
53	•	Bolt, Hex Hd., 3/8-16 x 2-1/4	x	x	x	×
54	48470	Pulley, Pump Shaft	X X	X'	X	X

^{*} Common hardware which should be purchased locally. All bolts Grade 5 plated, all other fasteners zinc plated.

ENGINE DECK CONT'D

See Page 3 For Illustration

REF. PART								
NO.	NO.	DESCRIPTION	14KA	14KH	18KH	20KHE		
56	42692	Belt Guide, Cutter - Rear	×	×	×	×		
57	48051	Spring, Pump Belt Idler	×	×	×	×		
58	*	Hex Nut, Elastic Stop Lock, 3/8-16	×	×	x	×		
59	*	Bolt, Hex Hd., 1/4-20 x 3/4	×	x	×	×		
60	48141	Taper Hub (for 48127)	x	×	×			
60	48378-03	Taper Hub (for 48378)				x		
61	48127	Pulley, Cutter Drive	x	x	x			
61	48378	Pulley, Cutter Drive				x		
62	04050-02	Retaining Ring, 3/4 Ext "E"	x	x	×	X		
63	48114-01	Grease Fitting	X	X	X	X		
64	46340	Idler Arm, Traction Belt (Includes bushings and grease fitting)	×	X	X	X		
65	45212	Pivot, Idler Arm	×	X	X	X		
66	+	Part Removed From Illustration			-			
67	48422	Pulley, Pump Drive	x	x	x			
67	48423	Pulley, Pump Drive				×		
68	04063-03	Key, 1/4 x 1/4 x 2-1/2	×	×	×	×		
69	48473	Pulley, Idler - Pump Drive	×	x	x	x		
70	48462-01	Oil Filter	x	x	x	×		
71		Hex Nut, #10-32	×	x	x	x		
72	*	Lockwasher, #10 Ext. Tooth	×	x	x	x		
73	*	Washer (.219 x .500 x .049)	×	x	x	×		
74	48305	Switch, Clutch Safety (black)	×	X	X	x		
75	*	Phillips Hd. Machine Screw, 10-32 x 1/2	×	x	×	x		
76	48485-02	Elbow, 45 deg. Male 7/8-14 JIC to Male 7/8-14 "O" Ring	x	x	×	x		
77	48475	Hose, Pump to Motor, LH - Forward	x	x	x	x		
77A	48477	Hose, Pump to Motor, RH - Forward	×	X	X	x		
78	48476	Hose, Pump to Motor, LH - Reverse	×	. X	X	X		
78A	48478	Hose, Pump to Motor, RH - Reverse	x	x	X	X		
79	48526	Lever, Dump Valve	x	×	x	X		
80	*	Setscrew, #8-32 x 3/4 Socket Hd.	×	X	X	X		
81	48205	Pad, Rubber				X		
82	+	Part Removed From Illustration	we have a		•			
83	04015-02	Setscrew, #10-32 x 3/4 Socket Hd.	· x	×	x	x		
84	*	Bolt, Hex Hd., 5/16-18 x 1-1/2	x	x	X	×		
85	**	Bolt, Hex Hd., 5/16-18 x 1	×	X	X	×		
86	04063-14	Key, 5.0 x 5.0 x 25mm	x	×	X	X		
87	04012-04	Setscrew, 5/16-18 x 3/8 Hex Socket Hd.	×	×	x	×		
NS	43096	Spacer, Oil Filter	x	x	x	×		

^{*} Common hardware which should be purchased locally. All bolts Grade 5 plated, all other fasteners zinc plated.

REPLACEMENT DECALS

SCAG

48314
Decal - Scag's Logo
(Located On Cutter Deck Cover - Top Surface)

FAST

SPEED CONTROL





48524 Decai - Speed Control (Located On Shift Quadrant)

DANGER

ROTATING BLADES AND BELTS

- . REEP HANDS, FEET & CLOTHING CLEAR
- . KEEP ALL GUARDS IN PLACE
- SHUT OFF ENGINE & DISENGAGE BLADE CLUTCH BEFORE SERVICING
- . CLEAR AREA OF DEBRIS BEFORE MOWN
- . USE CAUTION IN DIRECTING DISCHARGE
- . KEEP BYSTANDERS CHILDREN & PETS AWAY. READ INSTRUCTION MANUAL BEFORE OPERATING

48073

Decai - Danger, Rotating Blades (Located On Cutter Deck Cover -Near Discharge Chute)

HEAVY DUTY COMMERCIAL

48072

Decal - Heavy Duty Commercial (Located On Cutter Deck Cover - Front Wall)



H DANGER

SERIOUS BOOKLY-INJURY MAY RESULT FROM FAILURE TO FOLLOW SAFE OPERATING PROCEDURES.

BEFORE LEAVING OPERATOR'S POSITION, YOU MUST

- DISENGAGE CUTTER BLADES
- SHIFT TRANSMISSION TO NEUTRAL
- WAIT FOR ALL MOVEMENT TO STOP

READ OPERATOR'S MARIJAL FOR ADDITIONAL SAFETY GUIDES

44222

Decal - Operator Warning (Located On Back Of Fuel Tank)



72 61 48327 48320 48319 NOT SHOWN

48514
Decat - SCAG Zero Turn Redius
(Located on Oil Reservoir)



AYOID ENGINE DAMAGE CLOSE FUEL VALVE WHEN ENGINE IS NOT RUNNING

48281
Decal - Operator Warning
Fuel Fill
(Located On Top of Fuel Tank)




48071 Decal - O.P.E.I. Safety (Located On Cutter Deck Near Discharge Chute)



48079 Decal - Key Switch (Located Near Keyswitch)

HANDLE ASSEMBLY



HANDLE ASSEMBLY

	PART NO.	DESCRIPTION	14KA	14KH	18KH	20KH
1	45280	Handle Assy.				
2	42675	Quadrant, Speed Control	x x	X	X	X
2 3	420/3	Cotter Pin, 3/32 x 3/4	X X	X	X	X
3 4	04062-02	Hair Pin, Small		X	X	X
	•		X	X	X	X
5 6	04014-01	Capscrew, 1/4-20 x .75 Flat Hd. Hex Socket	X	X	x	X
	04040-09	Flat Washer, .656 ID x 1.312 OD x .095	X	x	x	x
7	45282	Speed Adjustment Lever	×	x	x	x
8	43086	Bushing, Speed Adjustment Lever	Χ.	X	x	X
9	*	Bushing, Speed Adjustment Lever Bott, Hex Hd., 3/8-16 X 1-1/4	X	x	x	x
10	48493-01	Ball Plunger	x	x	x	x
11	48092	Knob, Speed Adjustment Lever	x	x	X	x
12	*	Set Screw, 1/4-28 x 1 Knurled Cup Point	X	X	X	x
13	45142	Safety Interlock, Hand Grip - LH	X	X	X	X
13A	45141	Safety Interlock, Hand Grip - RH Bushing, Control Bod	x	. x	X	x
14	48312	Zaoming, common noc	X	, x	x	x
15	44014	Hod, Control Pivot	X	×	x	x
16	48326	Grip, Cutter Deck Engage	x ·	x	x	x
17	*	Boit, Hex Hd., 3/8-16 x 1-3/4	×	x	x	x
18	46090	Blade Clutch Lever Assy. (Includes grip)	x	x	x	x
19	04041-10	Flat Washer, 3/8 x 2 x 16 ga.	x	x	x	x
20	46076	Rod, Belt Clutch - Cutter	x	×	X	x
21	*	Carriage Bolt, 5/16-18 x 2-1/2, Rd. Hd. Sq. Nk.	×	x	x	x
22	48159	Grin Handle	×	x	. x	x
23	*	Hey Nut 5/16-18 Flastic Stop	x	. x	x	x
24	48324-01	Grip, Neutral Latch - RH		×	x	x
24	48324-02	Grip, Neutral Latch - LH	x	X	x	x
25	46083-01	Neutral Latch - RH (Includes grip)	×	X	X	x
25A	46083-02	Neutral Latch - LH (Includes grip)	x	x	x	X
26	04032-01	Curved Spring Washer	x	x	x	x
27	*	Flat Washer, 5/16	x	x	x	x
28	*	Bolt, Hex Hd., 5/16-18 x 2	x	x	x	x
29	48492	Grip, Steering Control	· x	x	x	x
	46333	Steering Control Lever - RH (Includes grip)	×	x	. x	x
30			×	· x	×	x
30A	46334 04026-01	Steering Control Lever - LH (Includes grip) Hex Nut, 9/16-18 Spring Steel	· 🗙		x	x
31		Spring, Grip Return	×	, X		x
32	48313				· x	
33	48021	Switch, Interlock (gold colored)	×	X	X	X
34	*	Bolt, Hex Hd., 1/4-20 x 2	x	×	X	X
35	*	Hex Nut, 1/4-20 Elastic Stop	X	×	X	X
36	*	Flat Washer, 3/8	×	×	x	x
37	*	Hex Nut, 3/8-16 Elastic Stop	x	X	X	X
38	48050	Spring, Compression	×	·. ^	X	X
39	*	Flat Washer, 25/64 x 15/16 x 12 ga.	X	x	x	×
40	*	Hex Nut, 3/8-16 Elastic Stop	X	×	X	x
41	*	Bolt, Hex Hd., 3/8-16 x 1	X	x	X	x
42	48017-02	Key, Ignition	x	x	x	x
43	48017-04	Hex Nut, 5/8-32	x	x	x	x
44	48017-03	Lockwasher, 5/8 Internal Tooth	x	x	x	x
45	48171	Switch, Ignition	x	×	x	
45	48017	Switch, Ignition				x
46	*	Bott, Hex Hd., 1/4-20 x 1/2	x	· x	×	x
47	*	Hex Nut, #10-32	. x	x	x	x
48	*	Lockwasher, #10 External Tooth	X X	x	×	x
49	48495	Wire Harness	3 x	x	x	
49	48496	Wire Harness				x
NS	48527	Wire Harness Adapter	x			
	48527	Machine Screw, #10-32 x 1/2 Phillips	x	x	x	×
50		Control Rod, Steering	x	x	x	x
51	46294	Retaining Ring, 5/8 Ext "E"	×	X.	×	×
52	04050-01					

^{*} Common hardware which should be purchased locally. All bolts grade 5 plated, all other fasteners zinc plate.


HANDLE ASSEMBLY CONT'D

See Page 7 For Illustration

	PART					
NO.	NO.	DESCRIPTION	14KA	14KH	18KH	20KH
		46 A 16 A				
54	04063-13	Key, 1/8 x 1/2 Woodruff #3	×	X	x	X
55	*	Setscrew, Hex Socket Knurled Cup Pt., 1/4-28 x 1/4	x	x	x	x
56	46335	Carn, Speed Control (Includes setscrew)	x	x	X	x
57	43157	Swivel Joint, Steering Rod	x	x	X	x
58	48100-04	Bushing	×	x	x	x
59	46336	Pivot, Pump Control Shaft (Includes bushings and grease fitting)	×	x	x	×
60	*	Bolt, Hex Hd., 5/16-18 x 1	x	X	X	x
61	04001-69	Bolt, Hex Hd., 5/16-18 x 1-3/4 Full Thread	x	x	x	x
62	48409	Bearing, Speed Control	· x	x	x	x
	43161	Spacer, Speed Control Bearing	×	x		
63					X	X
64	42730	Bar, Speed Control Adjustment	×	X	X	x
65	*	Lockwasher, 5/16	×	X	X	X
66	*	Hex Nut, 5/16-18	x	x	X	x
67	*	Boit, Hex Hd., 5/16-18 x 3/4	×	X	x	x
68	04065-05	Drive Pfn, 5/32 x 7/8 Type U	x	x	x	x
69	48051	Spring, Neutral Return	x	x	x	x
70	45292	Handle, Neutral Adjustment	· x	x	×	×
71	45271	Beilcrank, LH Control	×	x	X	×
71A	45272	Bellcrank, RH Control	x	X	X	X
72	48494	Spring, Speed Control	x	x	x	x
	48224	Bearing, Neutral Return	x	x	x	
73	48224					X
74		Bolt, Hex Hd., 3/8-16 x 3/4	X	X	x	×
75	48114-01	Grease Fitting, Straight 1/4-28	. x	X	X	X
76	46337	Neutral Cam, RH (Includes grease fitting)	×	×	X	X
76A	46338	Neutral Carn, LH (Includes grease fitting)	. , ; x	x	X	×
77 .	*	Hex Nut, 1/4-20	, · X	×	x	x
78	•	Lockwasher, 1/4	X	×	X	×
79	45094	Bellcrank Pivot Weldment	×	x	x	x
80	*	Bolt, Hex Hd., 1/4-20 x 1	x	X	X	x
81	44003	Rod, Blade Clutch - Lower	x	x	x	x
82	46339	Bellcrank, Cutter Engage (Includes grease fitting)	x	x	x	x
83	45295	Shaft, LH Pump Control	; X	X	X	X
84		Retaining Ring, 1/2" Ext "E"	X ·	X	. x	X
85	48091	Choke Control			×	×
86	48026	Switch, Neutral	×	X	×	X
87	48028-01	Cable Tie	x	×	x	X
88	48059-01	Clamp, Fuel Hose	x	x	X	X
89	48179-01	Fuel Hose, Short 7/32 ID x 3-1/2 (KA only)	x			
90	48057-02	Fuel Filter	x			
91	48058-05	Fuel Hose, 1/4 ID x 20	×			
91	48058-10	Fuel Hose, 1/4" x 10"		x		
91	48058-02	Fuel Hose, 1/4 ID x 14-1/8 (KH only)		• •	v	v
					X	X
92 .	48308	Vaive, Fuel Shut-off	X	X	X	X
93	48309	Bushing	×	X	X	X
94	48205	Pad, Rupber - Fuel Tarik - Lower	×	X	x	x
95	*	Machine Screw, 1/4-20 x 2 Round Hd. Slotted	x	X	x	x
96	42369	Strap, Fuel Tank	x	x	x	X
97	48292	Pad, Rubber - Fuel Tank - Upper	×	x	x	x
98	48311	Fuel Tank Cap	x	x	x	x
99	46174	Fuel Tank Assembly (Includes items 92, 93, 98 and decals)	· x	X	x	x
100	46295	Rod, Traction Control	x	x	x	×
		Bellcrank, Speed Control	x	x	x	x
101	45279	Belicrank, Speed Control				
102	40000	Carriage Bolt, 5/16-18 x 1 Rd. Hd. Sq. Nk. Oil Reservoir	X	X	x	X
103	45276		x	X	X	X
104	48535	Cap, Oil Reservoir	×	X	×	×
105	48394	Throttle Control	×	X		
105	48266	Throttle Control			X	×
106	43032	Swivel Joint, Speed Control Rod	x	x	x	x

^{*} Common hardware which should be purchased locally. All bolts grade 5 plated, all other fasteners zinc plate.

ELECTRIC START ELECTRICAL SYSTEM



REF. NO.	PART NO.	DESCRIPTION	SWZ 20KHE
1	48017	Key Switch	x
2	48297	Fuse Holder	×
2a	48298	Fuse 20 Amps	x
3	48016	Solenoid	x
4	48015	Battery may be purchased locally (U9-LM)	x
1 1 1 1 1 1 1 1 1 1 1 1 1 1 1 1 1 1 1	48496 48029-03	Wiring Harness Complete Battery Cable - 13-3/4" Red	x x
7 8	48029-01 48126	Sattery Cable - 13-3/4" Black Rubber Boot	X X
9	48021	Switch, Handle Interlock N.C.	· x
10	48305	Switch, Cutter Drive Interlock N.C.	x
11	48026	Switch, Neutral Interlock N.C.	x

WIRING DIAGRAM FOR MANUAL START

